

WINDOW HARDWARE

W
I
N
D
O
W
H
A
R
D
W
A
R
E



PM6576
RIGHT HAND, WINDOW LATCH

PM6568
LEFT HAND, WINDOW LATCH



006623001
RIGHT HAND, WINDOW LATCH

006623002
LEFT HAND, WINDOW LATCH



85450081
RIGHT SIDE LATCH LOCK, RAIL

85450082
LEFT SIDE LATCH LOCK, RAIL



PM7558
WINDOW LATCH SPRING, LARGE



PM6584
ACTUATOR, WINDOW LATCH



45000080
LATCH HANDLE



45003571
PUSHOUT, EMERGENCY WINDOW HANDLE



450103001
EMERGENCY WINDOW SWITCH



85450080
KIT-RETAINING PIN, SPRING AND BLOCK



THSP15004
DRIVER'S WINDOW LATCH KIT



THSP64001
SIDE SASH WINDOW LATCH CHANGED TO PART #TBBTHSP68022



TBBTHSP21101
METAL SWITCH KIT FOR PUSH OUT WINDOW WITH BASE AND HANDLE

WINDOW HARDWARE

W
I
N
D
O
W


H
A
R
D
W
A
R
E



85450071
EMERGENCY WINDOW
BUZZER SWITCH



TBBTHSP68022
WINDOW LATCH FOR
THOMAS C2. INCLUDES
LATCH, SPRING & CLIP



TBBTHSP84001
WINDOW SLIDER LOCK
KIT FOR THOMAS C2



TBBTHSP24001
THOMAS WINDOW LATCH KIT



PM1194
BLUE BIRD WINDOW
SWITCH KIT



PM5714
PUSH OUT WINDOW
SWITCH FOR BLUE
BIRD

WINDOW HARDWARE

W
I
N
D
O
W

H
A
R
D
W
A
R
E



PM7143
BLUE BIRD
WINDOW LATCH KIT



PM6390
WINDOW LATCH, R.H.
FITS BLUE BIRD



PM6391
WINDOW LATCH, L.H.
FITS BLUE BIRD



PM6392
WINDOW LATCH
SPRING
FITS BLUE BIRD



PM1862W
BLUE BIRD PASSENGER
WINDOW LATCH



2610206C92
WINDOW LATCH KIT
FOR IC