

WINDOW HARDWARE




PM6576

WINDOW LATCH. R.H.

PM6568

WINDOW LATCH, L.H.



006623001

WINDOW LATCH, L.H.

006623002

WINDOW LATCH, R.H.



85450081

RIGHT SIDE LATCH

85450082

LEFT SIDE LATCH



PM6584

ACTUATOR,
WINDOW LATCH



45000080

LATCH HANDLE



PM6390

WINDOW LATCH, R.H
FITS BLUE BIRD




PM6391

WINDOW LATCH, L.H.
FITS BLUE BIRD



TBBTHSP68022

WINDOW LATCH FOR
THOMAS C2. INCLUDES
LATCH, SPRING & CLIP



TBBTHSP84001

WINDOW SLIDER LOCK
KIT FOR THOMAS C2


WINDOW HARDWARE




TBBTHSP68022
WINDOW LATCH,
THOMAS C2




PM1862W
BLUE BIRD PASSENGER
WINDOW LATCH



2610206C92
WINDOW LATCH KIT
FOR IC



PM7143
BLUE BIRD
WINDOW LATCH KIT



TBBTHSP24001
THOMAS WINDOW LATCH KIT

WINDOW HARDWARE



85450071
EMERGENCY WINDOW
BUZZER SWITCH




450103001
EMERGENCY
WINDOW SWITCH



TBBTHSP21101
METAL SWITCH KIT FOR
PUSH OUT WINDOW WITH
BASE AND HANDLE



THSP15004
DRIVER'S WINDOW
LATCH KIT



PM1194
BLUE BIRD WINDOW
SWITCH KIT



45003571
PUSH OUT, EMERGENCY
WINDOW HANDLE

WINDOW HARDWARE




PM6400
EMERGENCY WINDOW SWITCH
FITS BLUE BIRD (#10036400)



PM5714
PUSH OUT WINDOW
SWITCH FOR BLUE BIRD



448288116
EMERGENCY WINDOW
SWITCH FOR THOMAS
AND IC



85450080
KIT-RETAINING PIN,
SPRING AND BLOCK



PM7558
WINDOW LATCH
SPRING, LARGE



PM6392
WINDOW LATCH
SPRING
FITS BLUE BIRD