

STOP ARM, CROSSGATE & HATCH PARTS



8639
ROOF HATCH
SWITCH



3029
FLASHER



3010
RELAY



5008K
CLUTCH ASSY
FOR 5 SERIES



7122-7K
CLUTCH DRIVER
FOR 7-SERIES

STOP ARM, CROSSGATE & HATCH PARTS

STOP
ARM
CROSS
GATE
HATCH
PARTS



8100
COMPLETE MAGNET
KIT FOR CROSSING
GATE



8118
MAGNET
ONLY



8204
MAGNET KIT FOR
INTERNATIONAL/NAV



71049
MAGNET
WITH PLATE



71052
PLATE ONLY



78260
STOW BRACKET
FOR IC CE 2024+



71018
STOW BRACKET
FOR CROSSING
GATE BLADE




71223
STOW BRACKET



6190K
STOW BRACKET
FOR 68177K

STOP ARM, CROSSGATE & HATCH PARTS



7178K
NEW DEFENDER
MOTOR FOR
CROSSING GATE &
STOP ARMS



5172K
5 SERIES MOTOR
W/HARNESS



7120-7K
7 SERIES
CONTROL
MODULE



7129
7 SERIES
CONTROL
MODULE


(This replaces the
6120 Series
Control Module.)



1800
SOLENOID
& REGULATOR

STOP ARM CROSSGATE HATCH PARTS


STOP ARM, CROSSGATE & HATCH PARTS



7190K

HARDWARE KIT FOR ELECTRIC
STOP ARM AND CROSSING GATES


STOP ARM, CROSSGATE & HATCH PARTS




2105K
HARDWARE KIT FOR STOP ARMS

STOP ARM, CROSSGATE & HATCH PARTS

STOP
ARM
CROSS
GATE
HATCH
PARTS



2106K
AIR DIAPHRAGM KIT
WITH HARDWARE



28109K
AIR CROSSING GATE
HARDWARE KIT

STOP ARM, CROSSGATE & HATCH PARTS

STOP ARM CROSSGATE HATCH PARTS



1975-030
HANDLE
REPLACEMENT
KIT




1975-034
SWITCH KIT
FOR ROOF
HATCH



1975-036
SWITCH KIT
FOR ROOF
HATCH



8930
DECAL KIT
FOR ROOF
HATCH



T1975-037
HANDLE REPLACEMENT KIT
FOR ROOF HATCH



T1975-052K
LINKAGE HARDWARE KIT
FOR TRANSPAC ROOF HATCH

STOP ARM, CROSSGATE & HATCH PARTS

STOP
ARM
CROSSGATE
HATCH
PARTS



T1975-040

ROOF HATCH ALARM
HARNESS KIT



106ASSY
DIAPHRAM W/PLATES



2196
STOP ARM & AIR
CROSSING GATE CABLE



170
OUTER
DIAPHRAM
PLATE

171
INNER
DIAPHRAM
PLATE



2198
STOP ARM & AIR CROSS-
ING GATE SPRING



2183
SPRING



194K
LENS KIT



548
STOP ARM DECAL



2114
PIN



176
BEARING
INNER



166
BEARING
OUTER

STOP ARM, CROSSGATE & HATCH PARTS



2166
HINGE BRACKET



2167
HINGE BRACKET



2169
HINGE BRACKET



28171K
ARM FOR AIR
CROSSING GATE



28174
HINGE ARM FOR AIR
CROSSING GATE



28158
HINGE ARM FOR AIR
CROSSING GATE


STOP
ARM
CROSSGATE
HATCH
PARTS

STOP ARM, CROSSGATE & HATCH PARTS


STOP
ARM
CROSSGATE
HATCH
PARTS



28409
HINGE FOR CROSSING
GATE



28242K
AIR CROSSING GATE
HINGE ARM KIT



78068K
CROSSING GATE
HINGE ARM FOR
THOMAS C2



28177
CROSSING GATE
COVER