

WINDOW HARDWARE



448288116
EMERGENCY WINDOW
SWITCH FOR THOMAS
AND IC



85450081
RIGHT SIDE LATCH
85450082
LEFT SIDE LATCH




PM6584
ACTUATOR,
WINDOW LATCH



PM6390
WINDOW LATCH, R.H.
FITS BLUE BIRD



PM6391
WINDOW LATCH, L.H.
FITS BLUE BIRD



TBBTHSP84001
WINDOW SLIDER LOCK
KIT FOR THOMAS C2


WINDOW HARDWARE




TBBTHSP68022
WINDOW LATCH FOR THOMAS C2.
INCLUDES LATCH, SPRING & CLIP




PM1862W
BLUE BIRD PASSENGER
WINDOW LATCH



2610206C92
WINDOW LATCH KIT
FOR IC



PM7143
BLUE BIRD
WINDOW LATCH KIT



TBBTHSP24001
THOMAS WINDOW LATCH KIT

WINDOW HARDWARE



85450071
EMERGENCY WINDOW
BUZZER SWITCH




450103001
EMERGENCY
WINDOW SWITCH



TBBTHSP21101
METAL SWITCH KIT FOR
PUSH OUT WINDOW WITH
BASE AND HANDLE



THSP15004
DRIVER'S WINDOW
LATCH KIT



PM1194
BLUE BIRD WINDOW
SWITCH KIT



45003571
PUSH OUT, EMERGENCY
WINDOW HANDLE